

SAFE BATTERY USAGE

- Use alkaline batteries for best performance and longer life.
- Use only the type battery recommended for the unit.
- Batteries should be replaced only by an adult.
- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Do not short-circuit batteries.
- When not used for an extended time, remove batteries to prevent possible leakage and damage to the unit.
- Do not mix rechargeable and non-rechargeable batteries.
- Rechargeable batteries are to be removed from the toy before charging.
- Rechargeable batteries are to be recharged only under adult supervision.
- Do not recharge non-rechargeable batteries.
- Exhausted batteries are to be removed from the toy.
- Do not dispose of batteries in fire as they may leak or explode.

FCC COMPLIANCE

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Modifications not authorized by the manufacturer may void users authority to operate this device.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device. CAN ICES-3 (B)/NMB-3(B).



'Let's care for the environment!'

The wheelee bin symbol indicates that the product must not be disposed of with other household waste. Please use designated collection points or recycling facilities when disposing of the item. Do not treat old batteries as household waste. Take them to a designated recycling facility.

Please keep this manual as it contains important information.



0417-0-E/INT

© Zapf Creation AG
Baby born® is an internationally registered trademark of Zapf Creation AG.
Manufactured and distributed under license by MGA Entertainment, Inc.
16300 Roscoe Blvd.
Van Nuys, CA 91406 U.S.A.
(800) 222-4685
Printed in China

MGA Entertainment UK Ltd.
50 Presley Way
Crownhill
Milton Keynes, MK8 0ES
Bucks, UK
+ 0800 521 558

Visit www.mgae.com
to register your product
and to enter our sweepstakes
(No purchase necessary)

The preferred method of contact for Customer Service is through our e-mail contact form at www.mgae.com



Puppy Doodle




AGES 3+ YEARS

SKU: 916045

ADULT SUPERVISION AND BATTERY INSTALLATION REQUIRED.

CONTENTS

A. 1 Puppy B. 1 Bottle C. 1 Bone



Illustrations are for reference only. Styles may vary from actual contents.

BATTERY INSTALLATION

Before beginning, an adult must install fresh alkaline batteries. Here's how:

1. Using a Phillips screwdriver (not included), remove the screws and battery compartment cover located under the dog (Fig.1).
2. Install two (2) fresh 1.5V AAA (LR03) alkaline batteries (not included) making sure the (+) and (-) ends face the proper direction as indicated inside the battery compartment.
3. Replace the compartment cover and tighten the screws.

NOTE: When replacing, the water jet should be through the cloth (Fig.2).




Fig. 1




Fig. 2

QUICK START

FEEDING PUPPY DOODLE WATER

Before beginning, cover the play area to prevent possible water damage.


1. Turn the switch to the on position as shown.
2. Fill the bottle with clear tap water and tightly replace the cap. Only use water as other liquids may block the tubes inside the dog.
3. Keeping the puppy at an upright position, push the bottle as far as possible into its mouth. It will make a slurping sound until you remove the bottle. After the puppy has been fed, it will bark.
4. To get the puppy to pee, press its back and the leg will lift. It will begin to pee with a realistic sound. Push the leg back to its original position when done. Press its back multiple times to drain the puppy fully.
5. Dry the puppy with a cloth after feeding and peeing.



FEEDING PUPPY DOODLE THE BONE

When feeding Puppy Doodle the bone, it should be horizontal and directly under the nose. The puppy will make crunching noises until you remove the bone and then it will bark.

NOTE: It will not work if the bone is placed under the nose vertically.



IMPORTANT INFORMATION

⚠ WARNING:

- Adult supervision is required when children are playing around water.
- Do not allow children to play with Puppy Doodle near an electrical source or apparatus in order to avoid electric shock and/or electrocution.
- Do not aim water jet at electrical devices, people or other living things.
- Keep moisture away from battery compartment.
- Clean the puppy with a damp cloth.
- Turn the puppy off after use to conserve battery power.
- Thoroughly drain and dry the puppy and bottle after each use and before storing.